FIG.1


DISPLAY DEVICE OR THE LIKE
9 SLIP HANDLING DEVICE
3
I/F SECTION
1 CONTROL SECTION
120
SWITCH CONTROL SECTION
110
IMAGE PROCESSING SECTION
2
IMAGE MEMORY
4
I/F SECTION
10 CAMERA SECTION
START SWITCH 14
CAMERA HEAD 11
SUPPORTING STRUT 15
MANUSCRIPT 13
12
MANUSCRIPT STAND

FIG.2



JP2004-193401

FIG.3


SET LOW DEFINITION
21
READ AND STORE IMAGE
40
READ IMAGE
22
28
REPLACE COMPARISON IMAGE
NOT YET STILL
MAKE STILLNESS DETERMINATION
23
STILL
SET HIGH DEFINITION
24
READ IMAGE
25
CONDUCT EXTERNAL OUTPUTTING
26

FIG.4


SET LOW DEFINITION
21
READ AND STORE IMAGE
40
31
MAKE SWITCH DEPRESSION DETERMINATION
DEPRESSION
NO
READ IMAGE
22
28
REPLACE COMPARISON IMAGE
23
NOT YET STILL
MAKE STILLNESS DETERMINATION
STILL
SET HIGH DEFINITION
24
READ IMAGE
25
STORE IMAGE IN IMAGE MEMORY
32
SET LOW DEFINITION
33
READ IMAGE
34
35
NO
MAKE SWITCH DEPRESSION DETERMINATION
STILL
36
NO
MAKE SWITCH DEPRESSION DETERMINATION
DEPRESSION
CONDUCT EXTERNAL OUTPUTTING
37

FIG.5A


SLIP READING IS READY.
DEPRESS THE SWITCH.

FIG.5B


THE SLIP HAS BEEN READ.
DEPRESS THE SWITCH.